

Panasonic

Laser Printer


Operating Instructions

Model No. **KX-P7100**

The KX-P7100 Operating Instructions consist of the following 2 files.


- **Print.pdf**
- **Mainte.pdf**

These files can be opened by clicking on their names below. The printer's features are described on the following pages of this file.



Settings and Printing (Print.pdf)

This section contains information on printer panel, printer driver and printing a document.



Maintenance and Specifications (Mainte.pdf)

This section contains information on cleaning the printer, replacing supplies, clearing jams, troubleshooting, error messages, repacking and specifications of the printer, media to be used and interface.

Please carefully read the Operating Instructions before operating.

Keep the printer CD-ROM in a safe place for future reference.

Do not expose the CD-ROM to direct sunlight or extreme heat and do not scratch or smudge the surface of the CD-ROM.

Features

Congratulations on your purchase of the KX-P7100. We are sure it will meet your printing needs and give you many years of productive and efficient use.

Paper handling

■ **Media tray** (universal cassette):

Enables to load 75 g/m² (20 lbs.) paper up to 250 sheets.

Transparency or envelope can be also loaded.

■ **Manual feed:**

Enables to load a media (paper, transparency, label or envelope) one by one.

Automatic Duplex Printing (see “Duplex Printing” on page 45 in “Settings and Printing”)

- Automatically prints your document on both sides of the paper.

Overlay (see “Overlay Printing - Watermark” on page 47 in “Settings and Printing”)

- Overlaps an overlay data (image or characters) over any document.

2 Up / 4 Up (see “Setting the Printer Driver” on page 22 in “Settings and Printing”)

- Prints 2 or 4 pages on a single sheet of paper to save paper.

Power Saving (see “Using the Printer Console Window” on page 41 in “Settings and Printing”)

- Saves energy while the printer is idle.

Animated Help Feature (see “Printer Status Display” on page 53 in “Settings and Printing”)

- The KX-P7100 Printer Status alerts the user of common operational errors. Click the ► button for animated help. This feature will walk you through the steps required to get your printer running once again.

Bi-directional Parallel Interface or USB Interface

(see “Specifications” on page 41 in “Maintenance and Specifications”)

- Enables communication between the computer and the printer using the parallel interface or USB.



As an ENERGY STAR® Partner, Panasonic has determined that this product meets the ENERGY STAR® guidelines for energy efficiency. (ENERGY STAR is a U.S. registered mark.)

Destiny™ and WinStyler™ are trademarks of Destiny Technology Corporation.

WinStyler™ Copyright 2001, Destiny Technology Corp. Ver. 2.0 All Rights Reserved.

The operating instructions are subject to change without notice.

© Kyushu Matsushita Electric Co., Ltd. 2001